

8W-63 POWER SEAT

Component	Page
Assembly-Seat Motor	8W-63-2
Fuse 4	8W-63-2
Fuse 58	8W-63-3
G300	8W-63-3
G301	8W-63-2
Heater-Cushion Pad-Driver	8W-63-3
Heater-Cushion Pad-Passenger	8W-63-3

Component	Page
Heater-Seat Back-Driver	8W-63-3
Heater-Seat Back-Passenger	8W-63-3
Module-Heated Seat-Driver	8W-63-3
Module-Heated Seat-Passenger	8W-63-3
Module-Integrated Power	8W-63-2, 3
Switch-Seat-Driver	8W-63-2



