

## 8W-47 AUDIO SYSTEM

<b>Component</b>	<b>Page</b>
Amplifier-Radio . . . . .	8W-47-2, 3, 4
Amplifier-Subwoofer . . . . .	8W-47-8
Antenna-Satellite . . . . .	8W-47-7
Circuit Breaker-Window/Door Lock (f30) . .	8W-47-8
Clockspring . . . . .	8W-47-6
Cluster . . . . .	8W-47-6
Fuse 6 . . . . .	8W-47-2, 7
Fuse 21 . . . . .	8W-47-3
Fuse 48 . . . . .	8W-47-8
G202 . . . . .	8W-47-2, 3, 8
G300 . . . . .	8W-47-8
G301 . . . . .	8W-47-7
Module-Front Control . . . . .	8W-47-2, 3, 7
Module-Hands Free . . . . .	8W-47-2

<b>Component</b>	<b>Page</b>
Module-Integrated Power . . . . .	8W-47-2, 3, 7, 8
Radio . . . . .	8W-47-2, 3, 5, 7, 8
Receiver-Satellite . . . . .	8W-47-7
Speaker-Left Front Door . . . . .	8W-47-4, 5
Speaker-Left Rear . . . . .	8W-47-4, 5
Speaker-Left Rear Door . . . . .	8W-47-4, 5
Speaker-Right Front Door . . . . .	8W-47-4, 5
Speaker-Right Rear . . . . .	8W-47-4, 5
Speaker-Right Rear Door . . . . .	8W-47-4, 5
Speaker-Tweeter-Left Front . . . . .	8W-47-4
Speaker-Tweeter-Right Front . . . . .	8W-47-4
Switch-Remote Radio-Left . . . . .	8W-47-6
Switch-Remote Radio-Right . . . . .	8W-47-6













