

8W-42 AIR CONDITIONING/HEATER

Component	Page
Actuator-Blend Door	8W-42-3
Actuator-Mode Door-Floor To Defrost	8W-42-3
Actuator-Mode Door-Floor To Panel	8W-42-3
Actuator-Recirculation Door	8W-42-3
Cluster	8W-42-4
Clutch-A/C Compressor	8W-42-5
Control-A/C-Heater	8W-42-2, 3, 4
Fuse 7	8W-42-5
Fuse 11	8W-42-5
Fuse 35	8W-42-4
Fuse 59	8W-42-2
G108	8W-42-5
G200	8W-42-2, 4

Component	Page
G201	8W-42-2
Module-Front Control	8W-42-2, 5
Module-Integrated Power	8W-42-2, 4, 5
Module-Powertrain Control	8W-42-5
Motor-Blower	8W-42-4
Relay-A/C Clutch	8W-42-5
Relay-Blower Motor	8W-42-4
Resistor-Blower Motor	8W-42-4
Sensor-Evaporator Temperature	8W-42-4
Switch-Ignition	8W-42-4
Transducer-A/C Pressure	8W-42-5









