



8W-40 INSTRUMENT CLUSTER

Component	Page
Clockspring	8W-40-3
Cluster	8W-40-2, 3, 4, 5, 6
Control-A/C-Heater	8W-40-3
Fuse 6	8W-40-2
Fuse 8	8W-40-5
Fuse 20	8W-40-2
Fuse 25	8W-40-2
G200	8W-40-2
G301	8W-40-2
Lamp-Center Bezel	8W-40-3
Lamp-Dome-Front	8W-40-6
Lamp-High Mounted Stop	8W-40-6
Latch-Door-Left Front	8W-40-4
Latch-Door-Left Rear	8W-40-4
Latch-Door-Right Front	8W-40-4
Latch-Door-Right Rear	8W-40-4

Component	Page
Module-Front Control	8W-40-2, 6
Module-Fuel Pump	8W-40-6
Module-Integrated Power	8W-40-2, 5
Sensor-Sun	8W-40-3
Solenoid-Brake Transmission Shift	8W-40-6
Switch-Headlamp	8W-40-5
Switch-Horn	8W-40-3
Switch-Multifunction	8W-40-3, 5
Switch-Parking Brake	8W-40-6
Switch-Remote Radio-Left	8W-40-3
Switch-Remote Radio-Right	8W-40-3
Switch-Seat Belt-Driver	8W-40-2
Switch-Transfer Case Selector	8W-40-3, 5
Switch-Window/Door Lock-Driver	8W-40-5
Switch-Window/Door Lock-Driver Express	8W-40-5
Switch-Window/Door Lock-Passenger	8W-40-5





■ REMOTE RADIO
 ◆◆◆ HIGHLINE

