

8W-43 OCCUPANT RESTRAINT SYSTEM

Component	Page
Airbag-Driver Squib 2	8W-43-3
Airbag-Passenger Squib	8W-43-3
Airbag-Side Curtain-Left	8W-43-4
Airbag-Side Curtain-Right	8W-43-4
Clockspring	8W-43-3
Cluster	8W-43-4
Electronics	8W-43-2, 4, 5
Fuse 20	8W-43-2
Fuse 21	8W-43-2
Fuse 39	8W-43-4
G301	8W-43-2
G303	8W-43-4
Module-Occupant Restraint	
Controller	8W-43-2, 3, 4, 5

Component	Page
Module-Totally Integrated Power	8W-43-2, 4, 5
Seat Belt Tensioner-Driver	8W-43-3
Seat Belt-Tension Reducer-Driver	8W-43-4
Seat Belt-Tensioner-Passenger	8W-43-3
Sensor-Front Impact-Left	8W-43-5
Sensor-Front Impact-Right	8W-43-5
Sensor-Seat Track Position-Driver	8W-43-5
Sensor-Side Impact-Left 1	8W-43-4
Sensor-Side Impact-Right 1	8W-43-4
Switch-Passenger Airbag On/Off	8W-43-2
Switch-Seat Belt-Driver	8W-43-4







